

# META EVOCAN

## IT Manuale d'uso universale

### 1. INTRODUZIONE

Caro Cliente,

Prima di lasciarla alla lettura del manuale d'uso per la specifica applicazione scelta, desideriamo complimentarci con lei per aver scelto un prodotto Meta System e siamo lieti di poterle fornire alcune indicazioni che potranno esserle particolarmente utili per conoscere meglio le prestazioni del sistema di allarme installato nella sua vettura. Il sistema d'allarme controlla che in sua assenza non vengano eseguite intrusioni all'interno dell'abitacolo, e che non venga sollevata l'auto al fine di rimorchiarla o rubare gli pneumatici. L'avverarsi di una qualsiasi delle suddette circostanze determina l'attivazione di un allarme ottico/acustico. Abbinando una sirena telematica T78 verrà recapitato l'evento georeferenziato direttamente al suo numero di telefono registrato nel contratto. Tramite un'APP dedicata sarà possibile tenere monitorato la posizione del veicolo. All'allarme è possibile abbinare sistemi di localizzazione indipendenti. L'allarme segnalerà un eventuale effrazione per permettere di notificarla ad una Sala Operativa o direttamente su una applicazione Utente.

### 2. FUNZIONAMENTO

In funzione alle caratteristiche tecniche del veicolo o alle proprie esigenze di sicurezza, è possibile configurare il prodotto **META EVOCAN** ad una specifica modalità funzionale. Al fine di darle informazioni più corrette possibili relativamente l'impianto installato, le chiediamo di identificare con il suo installatore di fiducia la configurazione scelta e scaricare le istruzioni sullo specifico funzionamento presenti nell'AREA TECNICA del sito [www.metasystemcorporation.com](http://www.metasystemcorporation.com).

#### CONFIGURAZIONI POSSIBILI:

- *RADIOCOMANDATO*
- *CAN BUS*
- *LIN BUS*
- *STAND ALONE ID-TAG*

### 3. AVVERTENZE

Il dispositivo ha esclusivamente una funzione dissuasiva verso eventuali furti. In nessun caso può essere considerato come un'assicurazione contro il furto. Il produttore garantisce il buon funzionamento del sistema in conformità alle normative vigenti e si riserva il diritto di effettuare variazioni in qualsiasi momento si rendessero necessarie senza l'obbligo di darne comunicazione. Si declina ogni responsabilità per guasti o anomalie di funzionamento del dispositivo, degli accessori o dell'impianto elettrico del veicolo dovuti ad una cattiva installazione e/o al superamento delle caratteristiche tecniche.

### 4. OMOLOGAZIONI

Il dispositivo **META EVOCAN** installato a bordo del suo veicolo è omologato secondo le seguenti direttive:

**2014\_53\_UE; UN-R10; UN-R116 (PART II, VAS)**



(da staccare e consegnare al proprietario del veicolo)

### CERTIFICATO DI INSTALLAZIONE



Il sottoscritto, \_\_\_\_\_ installatore, certifica di aver eseguito personalmente l'installazione del dispositivo di protezione del veicolo descritto qui di seguito, conformemente alle istruzioni del fabbricante.

#### DESCRIZIONE DEL VEICOLO

- Marca: \_\_\_\_\_
- Tipo: \_\_\_\_\_
- Numero di serie: \_\_\_\_\_
- Numero di immatricolazione: \_\_\_\_\_

#### DESCRIZIONE DEL DISPOSITIVO DI PROTEZIONE DEL VEICOLO

- Marca: \_\_\_\_\_ • Tipo: \_\_\_\_\_
- Numero di omologazione: \_\_\_\_\_
- Fatto a \_\_\_\_\_, il \_\_\_\_\_
- Indirizzo completo dell'installatore (e timbro): \_\_\_\_\_
- Firma: \_\_\_\_\_ (precisare le funzioni svolte) \_\_\_\_\_



# META EVOCAN

## EN Universal User Manual

### 1. INTRODUCTION

Dear customer,

Before you read the user instruction for the specific configuration chosen we wish to congratulate you for having chosen a MetaSystem product and we would like to give you some general information that you will surely find particularly useful in helping you to become completely familiar with all the features of your new alarm system for your vehicle. While you are away from the car the alarm ensures that no one opens any part of it and lift the vehicle to tow it or remove its wheels, all these events trigger a light and acoustic alarm. Combining the T78 telematic siren, the georeferenced event will be delivered directly to your telephone number registered in the contract. Through a dedicated APP it will be possible to monitor the vehicle position. The alarm unit can be combined with an independent tracking system. The alarm unit will signal any break-in to allow the notification to the Operations Room or directly to the user APP.

### 2. OPERATION

Depending on the vehicle technical characteristics and your own safety needs, it is possible to set up the **META EVOCAN** product to a specific functional modality. In order to give you the most correct information regarding the installed system we ask you to identify, with your trusted installer, the chosen configuration and download the relative instructions on specific operation in the TECHNICAL AREA of [www.metasystemcorporation.com](http://www.metasystemcorporation.com).

#### POSSIBLE CONFIGURATIONS:

- RADIO CONTROLLED
- CAN BUS
- LIN BUS
- STAND ALONE ID-TAG

### 3. WARNINGS

The device only has a deterrent function against possible thefts. In no case can it be considered as insurance against theft. The manufacturer guarantees the proper functioning of the system in compliance with current regulations and reserves the right to make changes at any time they become necessary without the obligation to give notice.

We decline all responsibility for failures or malfunctions of the device, accessories or vehicle electrical system due to incorrect installation and/or exceeding of the technical characteristics.

### 4. HOMOLOGATIONS

The EvoCan device installed on board your vehicle is approved according to the following directives:

**2014\_53\_UE; UN-R10; UN-R116 (PART II, VAS)**



(to be cut out and issued to the vehicle owner)

### INSTALLATION CERTIFICATE



I the undersigned, \_\_\_\_\_ professional installer, certify that the installation of the vehicle protection system described below has been carried out by myself in accordance with to the installation instructions supplied by the manufacturer of the system.

#### DESCRIPTION OF THE VEHICLE

- Maker: \_\_\_\_\_
- Type: \_\_\_\_\_
- Serial Number: \_\_\_\_\_
- Registration number: \_\_\_\_\_

#### DESCRIPTION OF THE VEHICLE PROTECTION SYSTEM

- Maker: \_\_\_\_\_ • Type: \_\_\_\_\_
- Homologation Number: \_\_\_\_\_

at \_\_\_\_\_, on \_\_\_\_\_

Installer's full address (and stamp, if appropriate): \_\_\_\_\_

Signature: \_\_\_\_\_ (please specify job position) \_\_\_\_\_